

powerpatch[®]

Leak Repair System Instructions



Sand or brush repair area



Clean area with Type TR™
before applying
PowerPatch® Putty



Apply putty ½ inch beyond
leak; ⅛ to ¼ inch thick

1. Clean surface with rag or American Polywater's Grime-Away™ Multi-Purpose Cleaner Wipes to remove dirt and grime.
2. Scrub the area to be sealed with a steel brush or sandpaper to remove loose particles and oxides, and to roughen the surface. Clean and abrade approximately 3" around the leak. If surface material is lead, follow prescribed work methods to avoid exposure to lead dust.
3. **Caution:** Wear nitrile gloves (provided) and safety glasses. Refer to MSDS of all products before handling.

For an active leak, apply PowerPatch® Putty to temporarily plug the fluid.

4. Cut off a portion of the PowerPatch® Putty Stick (approximately ½ inch), remove plastic wrap, and knead/mix by hand approximately 2 minutes, until material is well mixed and of uniform color. For a pinhole leak, shape putty into a plug the size of a large pea. For a leaking crack or seam, roll the putty into a rope about ⅛ to ¼ inch thick.
5. Wipe leak area with TR-1 solvent wipe to thoroughly clean the surface of contaminants, oils, and to displace any remaining water.
6. Apply the mixed PowerPatch® Putty plug or rope over the leak, spreading it out about ½ inch from all points of the leak area with a thickness of approximately ⅛ to ¼ inch. The putty will feel warm as it reacts. Apply constant pressure to this putty patch with the palm of the hand for 2–3 minutes until material feels firm. For the best, long-term seal, limit quantity of putty.

To seal polyethylene (or other low energy plastic), apply PowerPatch® Primer (EP-PRIMER) to prepared areas. This product is available separately and is not for use on metallic surface.

7. Use the second TR-1 cleaning wipe to clean surface again and let dry for 15 seconds. (On polyethylene apply primer after cleaning.)



Mix 2-part paste sealant to a uniform grey color



Apply PowerPatch® Sealant over putty patch or leak area



Smooth edges

Important: Mix and apply the PowerPatch® Sealant (steps 8 – 11) quickly.

8. Open one Part A Sealant cup (black paste) and one Part B Sealant cup (white paste). Remove the protective seal from the Part B Sealant cup and discard. A small amount of yellow skin or crust may form on contact with air. This will not harm the performance of the material. Discard any excess hard pieces.
9. Empty all the contents of the Part B Sealant Cup into the larger, Part A Sealant Cup. Mix for about 30–60 seconds until the mixture is a uniform color of gray. For larger repairs, two sets of Part A and B cups may be necessary.
10. Immediately apply the sealant to the prepared surface. Start with the edges of the putty patch and cover with PowerPatch® Sealant using light pressure. Spread the sealant to the surrounding area ½" to 1" beyond the leak or patch on all sides. Build a layer ¼ inch thick over the repair area.
11. Smooth the PowerPatch® sealant edges.
12. Application of the PowerPatch® Sealant should take about 2–3 minutes. The sealant has a working time of approximately 6 minutes and a functional cure in approximately 60 minutes, depending on ambient temperature. Do not move area of repair until functional cure is achieved. See chart below.

Temperature	Working Time	Functional Cure
35° F 2° C	40 Minutes	7 Hours
52° F 11° C	20 Minutes	3 ½ Hours
60° F 16° C	10 Minutes	1 ½ Hours
70° F 21° C	6 Minutes	60 Minutes
88° F 31° C	4 Minutes	40 Minutes

powerpatch®

Leak Repair Kit

Components for the repair of oil leaks in lead- sheathed enclosures, transformers, terminations and more.

Before using this product, the end user should conduct whatever evaluations are necessary to determine that the product is suitable for the intended end use. American Polywater expressly disclaims the warranties and conditions of merchantability and fitness for a particular purpose. American Polywater's only obligation shall be to replace such quantities of this product proven to be defective. Except for the replacement remedy, American Polywater shall not be liable for any loss, injury or direct, indirect or consequential damages resulting from product use, regardless of the legal theory asserted.

American Polywater Corporation

Stillwater, Minnesota 55082 U.S.A.
 1-800-328-9384 (USA & Canada only)
 Telephone: 1-651-430-2270
 FAX: 1-651-430-3634
 www.polywater.com
 custserv@polywater.com

APC R.M. #: 87351-001 11/04