

AirRepair[®]

Leak Repair System

Instructions

1. Cable should be as dry as possible. Pump standing water out of manhole. Wear nitrile gloves (provided) and safety glasses.
2. Clean and dry the area around the leak with a dry rag. Scrub the cable with a steel brush or sandpaper (provided) to remove loose particles. Follow prescribed work methods to avoid exposure to lead dust. The lead should be shiny. Polyethylene cables should be scuffed: 80-grit sandpaper works well.
3. Wipe cable with TR-1 solvent wipe to clean the surface and displace any remaining water.
4. **Polyethylene (plastic) jacketed cables:** Fully saturate a swab with Plastic Primer. The swab may need to be wetted six or more times to get enough primer into the leak area. Area should be completely coated. Primer will dry quickly, it should be sealed within one-hour of application. *Do not use Plastic Primer when sealing leaks on lead or other metal products.*
5. **Caution:** Wear nitrile gloves (provided) and safety glasses. Refer to MSDS of all products before handling.

IT IS HIGHLY RECOMMENDED TO RELEASE AIR PRESSURE OR SHUT OFF PRESSURE DURING THE REPAIR PROCESS.

6. Eliminate any backpressure in the area of the leak. Do not bleed other sections of the cable that are under water. If pressure can be released, continue to Step 7. If pressure cannot be released, use the Air Repair[®] Putty for a short-term seal. Follow the *Putty Instructions* BEFORE continuing with Step 7.

Important: Steps 7 - 9 must be done quickly.



Photo 1

7. Open one Part A Sealant Cup (Black) and one Part B Sealant Cup (White). On warm temperature aging, a yellow skin or crust may form on the curing agent, part B. This will not harm the performance of the material. Remove the layer of hard skin and set aside. Empty all the contents of the Part B Sealant Cup into the larger, Part A Sealant Cup. Mix for about 30-60 seconds until the mixture is a uniform color of gray. (See Photo 1) For larger repairs, two sets of Part A and B Cups may be necessary.

AirRepair® Instructions Continued

8. Immediately apply the sealant to the cleaned surface, covering the leak and surrounding area (approximately 3-cm radius). Build a layer 1-cm thick over the repair area.
9. Smooth the repair and taper the edge of the seal to the cable. (See Photo 2)
10. Application of the Air Repair® Sealant should take less than 2 - 3 minutes. The Sealant will cure in approximately 5 - 15 minutes and fully harden in 2 hours.




Photo 2

11. If the cable has been moved out of its normal position for repair, the best time to reposition is immediately after you have applied the sealant. Don't wait for full cure. The repair will be most effective if movement is limited.
12. Pressure to the cable may be turned back on in approximately 10 minutes, after the Air Repair® Sealant has cured.

Putty Instructions:

- A. Cut off a portion of the Air Repair® Putty Stick, remove plastic and knead/mix in hand approximately 2 minutes until material is well mixed and of uniform color.
- B. After approximately 2 minutes of kneading/mixing, material will feel warm to the hand. Apply the putty mix over the leak spreading it out about 3 cms from all points of the leak area with a thickness of approximately 1 cm. Continue to apply constant pressure with the palm of the hand for 2 – 3 minutes until material feels firm. Proceed with Step 7.

Important Notice: The statements here are made in good faith based on tests and observations we believe to be reliable. However, the completeness and accuracy of the information is not guaranteed. Before using, the end-user should conduct whatever evaluations are necessary to determine that the product is suitable for the intended use.

American Polywater expressly disclaims any implied warranties and conditions of merchantability and fitness for a particular purpose. American Polywater's only obligation shall be to replace such quantity of the product proven to be defective. Except for the replacement remedy, American Polywater shall not be liable for any loss, injury, or direct, indirect, or consequential damages resulting from product's use, regardless of the legal theory asserted.

Makers of Polywater® and Dyna-Blue® Cable Lubricants and Pull-Planner™ 2000 Software

American
Polywater®
Corporation

P.O. Box 53
Stillwater, MN 55082
U.S.A.
1-800-328-9384
1-651-430-2270
fax 1-651-430-3634

www.polywater.com(URL) custserv@polywater.com(e-mail)