



CLEANER FOR INSULATED_BUCKET TRUCKS



Specially Formulated Cleaner for Maintaining Insulated Bucket Trucks to Help Keep Workers Safe

Polywater® BOOM™ Prewash Wipes safely remove unwanted contaminants from fiberglass boom arms and buckets to prevent tracking hazards. BOOM Prewash is water soluble and simply rinses off with water. BOOM Prewash is available in packaging options to fit a broad range of cleaning, maintenance, and safety needs.



FEATURES AND BENEFITS

- **POWERFUL**
Removes grease, grime, tar, creosote, hydraulic fluid, salt, pine pitch, insects, and road debris before rinsing
- **GEL COAT SAFE**
Will not remove or adversely affect gel coat
- **APPROVED**
Recommended by boom truck manufacturers
- **CONVENIENT**
Large, pre-saturated cleaning wipes designed for overall or spot cleaning in the field
- **BIODEGRADABLE**
Water soluble

Polywater® BOOM™ Prewash Wipes



CATALOG #	PACKAGE DESCRIPTION	UNITS/CASE
B-1	Saturated 24" x 24" (71 cm x 71 cm) Towel	24
B-D72	72-Count Dispenser of 10" x 12 (25 cm x 30 cm) Wipes	6



SPECIFICATIONS AND APPLICATIONS

- **Testing:** Companies should follow boom truck manufacturer guidelines on the frequency of dielectric testing, proper cleaning practice, and other maintenance procedures. The ANSI A92.2-1990 Standard (Section 5.4.3) also addresses proper dielectric testing intervals and field inspections for aerial truck testing.
- **Guidance:** Common degreasers or solvents can harm and strip the gel coat on the boom, causing weak or soft spots. Many crews have access to solvents and know how well they remove grease, but such solvents can be harmful to the fiberglass portion of the boom arm or bucket. Some cleaners contain abrasives and leave a considerable residue. Others, like acetone, xylene, and toluene, can cause permanent damage if left in contact with the surface too long. These solvents are also flammable and often hazardous. Personnel should be trained to use only BOOM Wipes for the boom and bucket areas to keep the truck in proper working order.

For more information, read our BOOM Cleaning Guidelines:
<https://www.polywater.com/en/resource/boom-cleaning-guide/>



- **Protect:** After cleaning a boom or bucket truck with BOOM Wipes, the fiberglass areas should be treated with Polywater Wax to protect the gel coat surface. Available in bulk 16oz (475 ml) bottles (catalog # W-16) or pre-saturated wipes (catalog # W-1).

polywater.com | +1 651-430-2270

Polywater[®]
Solutions at work.

IMPORTANT NOTICE: The statements here are made in good faith based on tests and observations we believe to be reliable. However, the completeness and accuracy of the information is not guaranteed. Before using, the end-user should conduct whatever evaluations are necessary to determine that the product is suitable for the intended use.

American Polywater expressly disclaims any implied warranties and conditions of merchantability and fitness for a particular purpose. American Polywater's only obligation shall be to replace such quantity of the product proven to be defective. Except for the replacement remedy, American Polywater shall not be liable for any loss, injury, or direct, indirect, or consequential damages resulting from a product's use, regardless of the legal theory asserted.

© 2022 American Polywater Corporation LIT-BOOMFLYER/REV000

American Polywater Corporation
11222 60th Street N.
Stillwater, MN 55082 USA

+1 651-430-2270 Main
+31 10 233 0578 Europe, Middle East, N. Africa
email: support@polywater.com