

Polywater® Fiberglass Wax & Buff Kit

INSULATED FIBERGLASS WAX



Waxing protects the gel coat

Hot Stick and Insulated Boom Truck Protectant

PRODUCT BENEFITS

- **Protects:** Does not remove or affect gel coat. Leaves non-conductive, water-repellent coating.
- **Fast Acting:** Wax applies easily and hazes quickly.
- **Convenient:** Dual-action tandem pack—wax-saturated wipe and dry buffing towel.
- **Restores:** Brings back luster and helps to protect gel coat.
- **IEEE Compliant:** Meets IEEE maintenance recommendations (Std #978).

Regular Maintenance is the Key to Safety

Regular inspection and cleaning of live line tools and insulated boom trucks after they've been dielectrically tested is required by OSHA to keep them in safe working order. Waxing the insulated fiberglass areas of boom trucks and hot sticks between testing periods protects the gel coat from degradation.



Catalog # W-1



Restoring the luster on fiberglass



Catalog # W-16



Catalog # W-1

Packaging for All Types of Applications

The Fiberglass Wax and Buff Kit contains a lint-free, wax-saturated wipe and a soft, lint-free towel for buffing. The W-16 16-ounce bulk package is recommended when servicing insulated fiberglass areas on boom trucks. Polywater Wax is formulated especially for hot sticks and insulating boom arms to haze quickly and buff out easily. This carnuba-based wax restores the luster of the fiberglass to help protect the gel coat. It beads water on the insulating surface to inhibit tracking.

POLYWATER WAX

Catalog #	Package Description	Units/Case
W-1	Saturated 8" x 12" / 20 cm x 30 cm wipe with dry buffing towel	72
W-16	16-oz. can (475 mL)	12

SPECIFICATIONS AND APPLICATIONS:

- Best Practice:** Once a boom has been properly cleaned with Polywater Boom Cleaner, Polywater Wax should be used to protect the gel coat surface and force water beading during misty or wet weather. All products used on boom trucks, including cleaners and protectants designed specifically for fiberglass booms, should be approved by the aerial lift manufacturer. American Polywater products are approved by boom truck manufacturers. Refer to our boom truck cleaning and maintenance best practice for more detailed information to keep your fleet in proper working order. www.polywater.com/wp-content/uploads/pdf/LIT-BOOMguide.pdf
- Industry Recommendations:** Companies should follow boom truck manufacturer guidelines on the frequency of dielectric testing, proper cleaning practice, and other maintenance procedures. The ANSI A92.2-1990 Standard (Section 5.4.3) also addresses proper dielectric testing intervals and field inspections for aerial truck testing. Follow manufacturer and industry guidelines on the maintenance of boom trucks for safe and long-lasting aerial fleets.

CONTACT US

1-800-328-9384 Toll Free

1-651-430-2270 Main

1-651-430-3634 Fax

email: support@polywater.com

IMPORTANT NOTICE: The statements here are made in good faith based on tests and observations we believe to be reliable. However, the completeness and accuracy of the information is not guaranteed. Before using, the end-user should conduct whatever evaluations are necessary to determine that the product is suitable for the intended use.

American Polywater expressly disclaims any implied warranties and conditions of merchantability and fitness for a particular purpose. American Polywater's only obligation shall be to replace such quantity of the product proven to be defective. Except for the replacement remedy, American Polywater shall not be liable for any loss, injury, or direct, indirect, or consequential damages resulting from product's use, regardless of the legal theory asserted.

American
Polywater[®]
 Corporation

11222 60th Street N | Stillwater, MN 55082 USA